



Adventure Unleashed, Bounce Without Bounds!



USER MANUAL

Adventure Unleashed, Bounce Without Bounds!

**WARNING:**

FAILURE TO FOLLOW THESE INSTRUCTIONS
COULD RESULT IN SERIOUS INJURY OR DEATH.

**Questions? Contact Us First****Please Do NOT return the product to the store.**

If you have any questions or concerns, please contact our customer support team first.

Email: support@hemopow.com (Response within 24 hours)

Phone: +1 (833) 228-2278 (Mon–Fri, 10:00 AM – 6:00 PM ET)

Warm Reminder:

If you need to return the item, please contact us to obtain the official return address.
Kindly do not send it directly back to the store.

**WARNING:**

- Adult set-up and supervised required. Keep children away from the blower.
- Do not use extension cords with this inflatable device. Outdoor use only.
- Do not place the inflatable device near or under overhead electrical lines.
- Keep all electrical lines, radios, speakers and other electrical devices away from the inflatable device.
- Precautions should be observed during handling and use to prevent electric shock.

SAFETY WARNINGS: READ ALL INSTRUCTIONS BEFORE ASSEMBLING THIS INFLATABLE DEVICE. FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN SERIOUS INJURY OR DEATH.



- Slide feet first only.
- Clear splashdown area after exiting slide.
- Do not stand up on the slide platform.
- ONLY one child will be allowed at a time on each slide and climbing wall.
- Do not use this product if you have any existing medical conditions. Ask your doctor if you have any concerns.
- Do not use this product if you are pregnant.
- Keep this inflatable device away from heat and open flame at all times.
- Do not use in direct sunlight when temperatures exceed 90 °F (32 °C). It may cause thermal burns due to heated surface.
- Always check the product and all its anchorage points during use, and re-secure if necessary.
- Keep children away from electrically operated products.
- Ensure electrical source is stable and safe before operation.
- Must be anchored firmly and securely using stakes. Installation is only permitted on soft ground.
- Before and during use, check for air loss. Make sure blower is properly connected to air tube.
- Always check for excessive air loss. Re-inflate the equipment to the specified pressure before resuming use.
- The blower must operate continuously to ensure airflow safety while children are playing.
- Prohibit children from walking on the slide section where the electric blower is installed.
- Do not insert foreign objects (e.g., tools, debris) or body parts (fingers, toes) into the blower. This may cause serious injury.
- Do not leave this product outside during non-use periods. Extended exposure to sunlight or extreme weather conditions may cause irreversible damage.
- Remove all children before deflate the inflatable products.
- This product must be thoroughly dry after use and before storage.

If product contains a pool:

- Adult supervision required.
- NEVER leave it inflated or full of water overnight.
- Drain water immediately during non-use periods.
- Do not jump or dive into the pool area.
- Keep pool area clean to prevent illness. No food or drink in the pool.
- NEVER drink pool water.
- Prior deflation, turn off the garden hose, remove water hose and disconnect tubing.

Safety Instructions

⚠ WARNING! MUST READ AND UNDERSTAND SAFETY INSTRUCTIONS BEFORE ASSEMBLING AND ENTERING THIS INFLATABLE DEVICE.

- Children must be accompanied by an adult ALL TIMES.
- Closely watch children who are in or near the pool. Children, especially toddlers at high risk of drowning.
- NEVER leave players unattended at any time. Instruct children on proper use of this inflatable device.
- No shoes, goggles, or any loose objects into the play area.
- Keep pets away from this product.
- No sharp objects into play area.
- Do not allow other toys or objects inside the product.
- Do not let children play together who are unevenly matched in sizes.
- ALWAYS climb in an upright position, placing feet on each step, and placing hands to grab safety handles.
- Children can drown in a very small amount of water. Empty the pool during non-use periods.
- Do not slide down on your stomach or head first.

SAFETY WARNINGS: Set Up

- ⚠ WARNING!** This inflatable device must be supervised and set up by an adult. Never place on concrete, wood, asphalt, packed earth or other hard surfaces. Falls onto hard surfaces can result in dead or other serious injuries.
- Do not use this product if wind speed exceeds 15 mph.
- Do not set up in windy or rainy conditions: wind may lift the product off of the ground.
- Never drag across rough surfaces.
- Only blower should be used for inflation.
- Ensure a 7-ft. (2.1-m) obstacle-free zone surrounds the product.
- Do not use extension cords with this product.
- Make sure the blower securely anchored to the ground before use this inflatable device.
- Installing safety barrier to keep children from gaining access during non-use periods.
- Place on level ground and firm soil or grass to allow proper use of stakes.

SAFETY WARNINGS: Blower

- ⚠ DO NOT USE EXTENSION CORDS WITH THIS PRODUCT. USE ONLY ON GFCI PROTECTED RECEPTACLES. KEEP CHILDREN AWAY FROM THE BLOWER.
- Adult supervision required. Do not leave blower unattended.
- The blower must be securely staked to the ground before use.
- Only use with Ground Fault Circuit Interrupt (GFCI) protected receptacle.
- Always test the blower AC adapter before use.
- Do not open the blower. If blower needs servicing, please take it to reputable dealer.
- Do not immerse the blower into water or expose to rain.
- Do not plug in or unplug the appliance with wet hands or while standing in water or rain.
- Do not insert small objects into any parts of the blower.
- Do not use the blower with any solid-state speed control device to reduce the risk of fire or electrical shock.
- Do not direct stream of air at face or body to avoid risk of injury.
- This product is intend to outdoor use only.
- Always unplug the blower before servicing.
- Do not operate the blower with a damaged cord or plug.

⚠ CAUTION: KEEP BLOWER AWAY FROM WATER, TRAFFIC AND CHILDREN. THIS BLOWER IS A HIGH VOLUME FAN, AND IS CAPABLE OF MOVING LOTS OF AIR VERY QUICKLY.

Unfolding



1.Remove contents from the storage bag.



2.Unwrap drawstring.



3.Unroll and unfold the product.



4.Pull from the center of the design area.

Blower Set Up



1.Attach the air tube onto the mouth of the blower motor.



2.Wrap drawstring around and tie it securely. Keep children away from blower.



Inflating

1.Always Test the Blower AC Adapter Before Use:



- 1)Plug in GFCI device.
- 2)Press RESET.
- 3)Press TEST.
- 4)Press RESET to use product.

⚠ DO NOT USE if the button fails to disable the blower.



2.Ensure a 7-ft. (2.1-m) obstacle-free zone surrounds the product.



3.Staked the product and blower securely to the ground before use.

4.Plug the blower into a properly grounded GFCI outlet, switch power ON. Product will inflate in 3 minutes.



⚠ WARNING Blower must be running continuously inflate during use. Do not try to repair or seal seams if you hear air flow out of fabric. This is intend to allow air through seams.

If product contains a pool:



5.Fix the water hose with Velcro.



6.Attach garden hose to the end of the tubing assembly.

Deflating



1.Turn OFF and unplug the blower fan from the outlet.



2.Unhook the strap on the blower tube to allow air to escape.



3.Unzip the zipper to speed up the deflation process.



4.Pull out the stakes around the unit and pack them up.


If product contains a pool:



5.Take off the shoes before entering the product.



6.Walk from front to back to remove any remaining air towards the blower tube.



7-1. Turn off the garden hose and disconnect plastic tubing.




7-2. Deflate the collapsible pool wall by pressing it downward to expel trapped water. Ensure all electrical devices are disconnected first.

Folding



1.To clean, wipe with a dry cloth. Thoroughly dry the unit before rolling up.



2.Make two half folds to the middle and walk around to remove air.



3.Fold in the half fold and walk around removing remaining air.



4.Keep pushing and flattening the roll as you go.

Storage



1.Looping the end of strap around and tight a tie slipknot.



2.Place the storage bag over the end of unit.




3.Tie the bag closed.



4.Store the unit and blower indoors in a dry place.


Repair Instructions WARNING: This is not a toy. Keep out of reach of children. Adult use only.



1.Cut the patch and ROUND the corners. (Corners cannot be sharp.)



2.Apply repair glue on damaged area and repair patch.



3.Position the patch over damaged area and smooth out bubbles.



4.Press firmly to ensure an even seal and allow to sit for 30 minutes before re-inflating.

CAUTION: Always deflate this product before repair the damaged area.

Maintenance

- Unplug and store the blower indoors in a dry place during non-use periods.
- Do not immerse the blower in water. To clean, wipe with a damp cloth.
- Store the blower upright position on a stable surface.
- If the product includes a water hose, clean it with a dry cloth. Make sure to use a dry cloth or a cloth soaked in a neutral solution/water to wipe the surface.
- Never store this product in wet. Thoroughly dry before rolling up.

Visual Determination of the Wind Speed

Use this table to determine the wind speed while the device is inflated. If the wind speed exceeds the maximum allowable wind speed, deflate the inflatable.

Beaufort Scale

Beaufort number	Wind Speed (mph)	Seaman's term		Effects on Land
0	Under 1	Calm		Calm; smoke rises vertically.
1	1-3	Light Air		Smoke drift indicates wind direction; vanes do not move.
2	4-7	Light Breeze		Wind felt on face; leaves rustle; vanes begin to move.
3	8-12	Gentle Breeze		Leaves, small twigs in constant motion; light flags extended.
4	13-18	Moderate Breeze		Dust, leaves and loose paper raised up; small branches move.
5	19-24	Fresh Breeze		Small trees begin to sway.
6	25-31	Strong Breeze		Large branches of trees in motion; whistling heard in wires.
7	32-38	Moderate Gale		Whole trees in motion; resistance felt in walking against the wind.
8	39-46	Fresh Gale		Twigs and small branches broken off trees.
9	47-54	Strong Gale		Slight structural damage occurs; slate blown from roofs.
10	55-63	Whole Gale		Seldom experienced on land; trees broken; structural damage occurs.
11	64-72	Storm		Very rarely experienced on land; usually with widespread damage.
12	73 or higher	Hurricane Force		Violence and destruction.

| Frequently Asked Questions

What if there is air leakage at the product's seams?

A: Minor air leaks through pinholes or seam junctions are normal. These ensure balanced internal pressure and prevent over-inflation.

Should I turn off the blower after inflating the product?

A: Do not turn off the blower during use, as this may cause the castle to deflate.

Found pinholes in some parts of the product. Is this a problem?

A: The product may have small pinholes (under 6mm) from production stitching. These do not affect normal use.

How to store a water-play inflatable product?

A: Water ingress is common. If it occurs, drain by tilting and drying at an angle. Ensure complete dryness before storage in a cool, ventilated area.

Why are bubbles forming at the seams when playing with water?

A: Bubbles at the seams are a physical phenomenon during water use. The product has passed lab chemical tests and meets safety standards. This is designed to ensure stable air pressure, not a quality issue.

| Customer Service

Warm Reminder:

If you need to return the item, please contact us to obtain the official return address. Kindly do not send it directly back to the store.



+1 (833) 228-2278 (Mon -Fri, 10AM - 6PM ET)



support@hemopow.com (Response within 24 hours)